

Кръмбъл е сладко еленче, което знае какво иска и наистина има нужда от твоите обич и грижи! Научи се как да разбираш какво иска и как да се грижиш за него – очите му светят в синьо, когато не се чувства добре, и светят в светли цветове, когато му е добре! За да включиш еленчето превключи бутона на позиция ОN. Бутонът се намира на коремчето.

Буден съм!

Кръмбъл е готов да играе с теб. Премига с очите и те вика! Когато очите му светят в синьо, той има нужда от твоите грижи и прегръдки!

Гладен съм!

Когато Кръмбъл те вика и мига със сини очи, може и да е гладен. Нахрани го с плодове и виж как яде (приближи и натисни плодовете до средата на нослето му за няколко секунди (карт.1). Когато е щастлив, очите му ще засветят в оранжево! Когато се нахрани, ще ти благодари, като издава щастливи звуци,

Кръмбъл е малко еленче и обича да го милваш и прегръщаш! Помилвай го по гърба (карт.2) и ще ти благодари като раздвижи очите си и светнат в оранжево.

Изплашен съм!

Когато Кръмбъл чуе силен шум той ще се изплаши и ще издаде звук, очите му ще светят в синьо и той ще ги затвори! За да го успокоиш опитай да го нахраниш или да го погалиш по

Скучно ми е, искам да си играем!

Ако Кръмбъл те вика, а ти не си играеш с него, на него му става скучно, премига, очите му светват в синьо и ще заспи. Когато заспи, Кръмбъл може да се събуди в следващата една минута, ако го погалиш или ако чуе силен шум.

Време е за сън!

Ако не искаш да играеш с Кръмбъл, той ще затвори очи и ще заспи. Натисни бутона на OFF и след това на ON за да го събудиш.

ВНИМАНИЕ! Кръмбъл може да изпълнява по една команда (функция) наведнъж. Не се опитвайте да го карате да прави ново действие преди да е приключил предното, освен във функция Изплащен съм, когатол може да му давате храна и да го милвате по гръбчето, за да го успокоите. Когато приключите играта, натиснете бутона на коремчето му на позиция ОГЕ. Внимавайте Кръмбъл да няма контакт с вода. За да почистите играчката използвайте влажна кърпа и почиствайте само повърхността.

ENGLISH

Crumble is a cute baby reindeer who lets you know what he wants and really needs your love and care. Learn how to understand his needs and to look after him; his eyes are blue when he feels uncomfortable, and turn bright when he feels happy! To play with Crumble, move the switch on the battery pack, located underneath his tummy, to the ON position.

I'm awake!

Crumble is ready to play with you, he blinks his eyes and calls for you! When his eyes turn blue he needs your cuddles!

I'm hungry!

When Crumble calls for you and blinks his blue eyes, he may be hungry. Give him his berries and you will see how he eats them! (Press the Berries accessory onto the middle of his muzzle) for several seconds (Picture 1). As Crumble is now happier, his eyes will light up in orange! When he is full he will thank you making happy noises!

Caress me!

Crumble loves to be caressed and cuddled! Caress him on his back (Picture 2). He'll thank you by moving his eyes, and they will light up in orange!

I'm scared!

If Crumble hears a loud noise he will be scared, his eyes will turn blue and he will close them! In order to calm him down, try to give him his berries or caress his back.

I get bored, I want to play with you!

If Crumble calls for you and you do not play with him, he gets bored and blinks his eyes as they turn blue... he's going to fall asleep! Once Crumble is asleep, he will wake up by being caressed or if he hears a loud noise (only up to one minute after he has fallen asleep).

I'm going to sleep!

If you do not play with Crumble he will close his eyes and fall asleep. To re-start Crumble, move the switch under his tummy to OFF and then back to ON again.

NOTE: Crumble is able to perform one action at a time. Do not try to make Crumble perform a new action until he has finished the previous action, except in "I'm scared" mode, where you can give him his berries or caress his back to calm him down. When you have finished playing with Crumble, move the switch under his tummy to the OFF position. Handle Crumble with care and do not let him come into contact with water. To clean Crumble, use a damp cloth on the surface of the plush only.



ВG: ОБЕЗВРЕЖДАНЕ НА ОТПАДЪЧНИ ЕЛЕКТРИЧЕСКИ УРЕДИ (ДИРЕКТИВА 2012/19/ЕС)
Символът, представляващ зачертана с кръст кофа за боклук на колепца, означава, че в края на полезния си живот продуктът не трябва да се изхвърля заедно с битови отпадъци, а трябва да бъде предаден в най-близкия събирателен пункт или съоръжение за рециклиране. Другите варганти са (а) да се обърнете към търговеца, от който е закунен продуктът, и да го върнете, когато купувате нов, при съотношение едно към едно съгласно член 11, точка 1, (б) да го замените безплатно без задължение за покупка, когато става дума за маломерии ОЕБО (с габарити под 25 см в търговски обекти с търговска площ за продажба на ЕБО не по-малка от 400 кв.м) съгласно член 11, точка 3. Правилното обезвреждане насърчава рециклирането на части и сутовнии и допринася за защита на околната среда и човешкото здраве. Действащото законодателство предвижда строти санкции за незаконното обезвреждане на продукти. За повече информация относно събирането на специални отпадъци,

моля, свържете се сместните власти.
Ex: DISPOSING OF ELECTRICAL APPLIANCES (DIRECTIVE 2012/19/EU)
The wheelie bin symbol with a cross indicates that the product must not be disposed of in the domestic waste at the end of its useful life. Instead, it should be taken to your nearest designated collection point or recycling facility. Alternatively,(a) check with your retailer and return the product when buying a replacement, on a one-to-one basis pursuant to article 5, comma b, (b) disposal free of charge with no obligation to purchase for small-sized WEEE (external dimension below 25cm in retail stores with a sales area of EEE of at least 400m2) pursuant to Article 5, comma c. Appropriate disposal promotes the recycling of parts and materials, as well as helping to protect the environment and human health. Under current legislation, strict penalties are enforced against those disposing of products illegally. For more information about the collection of special waste, contact your Local Authority.





Вносител: Комсед АД, ул.Тодор Каблешков 76, 1404 София, България, тел.: 02/9589915, www.comsed.net